

Preventive action - replacing main PCB.

This document is only intended for internal use and for authorized service partners.

Product category:	Washing machines
Affected models:	CTM3714V
	Batch:
	C1321001
	C1321901
	C1343201
	C1343601
	C1344501
	C1374201
	C1432601
	C2123601
	C2123701
	C5148001
	C5148101
	C5148501
	C5154001
	C7013401
	C7014001
	D7924601
	D7942901
	D7999901
	F6702401
	G2743401
	G2746001
	G4681801
	G4684101
	G7409401
	G8836601
Release:	1.0, 2023-06-12

Description:

Improvements has been made in production line of the main PCB. To ensure our high-quality standards the main PCB shall be replaced if the machine is within one the affected batch numbers (see above) and...

- ... there are problems with the main PCB.
- ... you are about to visit an affected model in another service matter.

Required spare parts:	 Main PCB – (spare part is sent F.O.C. from Elon Group. Note! DO NOT order from Aswo!) 		
	Green round sticker		
Recommended tools:	Standard equipment		

Action:

1. Replace the main PCB. Make sure all connections are properly fitted.

3. Undo the control panel and PCB

I. Departing the top cover II. Draw out the detergent drawer.

III. Loosen two screws fit on the control panel.

IV. Loosen two screws fit on the control panel.

V. Take out the control Panel inclined from the panel.

VI. Extract the cycle select knob

VII. Pull out the wire and press the buckle to take out the PCB.









2. Put the green sticker on the corner of the serial number label. This is mandatory and is done to make visible that this action has been carried out on the device



When performing this action, check that the washing machine is installed according to related standards regarding electrical equipment in humid environments. The machine is manufactured with protection rating IPX4

IRIS-code:

Condition	Symptom	Action	Defect	Component
-	-	Р	Т	G12