






C14	机械童锁	Mechanical child lock	1	
H01	显示板	display board	1	
C11	控制面板支架	control panel bracket	2	assemble with silica gel
C12	控制面板玻璃	control panel glass	1	附注-4
C36	控制面板托架	control panel holder	1	
C17	控制面板海绵	control panel sponge	2	
C18	控制面板保护膜	film of control panel	1	
C19	旋钮总成	Knob Assembly	2	
C17+C20	控制面板总成	control panel ass'y	1	
C30	硅胶	Silica gel	1	



H02	把手支架	handle support	1	
D14	导轨支架(左)	Rail bracket(Left)	1	
D13	导轨支架(右)	Rail bracket(Right)	1	
A11	烤叉托架	Roasted fork	1	
A63	旋转烤叉	rotisserie rack	1	
G18	热风电机	convection motor	1	
A15-2	烤盘(浅)	bake tray(shallow)	2	
A15-1	烤盘(深)	bake tray(deep)	1	
G23	旋转电机	rotisserie motor	1	
G20	温度传感器	temperature sensor	1	
A61	金属加热管(上)	metal heating element(top)	1	
A12	烤架	bake rack	1	
I40	排气管	exhaust pipe	1	
A62	涡轮增压管	turbo heating element	1	
I19	隔热保温盖	insulation cover	1	
I26	后隔热板	back insulation	1	
A32	腔体隔热板	Cavity insulation	1	
A30	腔体	cavity	1	
A53	下加热管及罩	under heating element & cover	1	
G20-1	探针温度传感器	probe temperature sensor	1	
A43	热风叶片	convection fan blade	1	
A42	热风电机罩	convection motor cover	1	
G10	灯	lamp	1	
No.	名称	Name	QTY	备注
设计	日期	共 页 第 页		cavity ass'y 腔体组件
校 对	日 期			
工 艺	日 期			
批 准	日 期			
		美的厨房电器 厨具公司		A00