


SPARE PARTS LIST

Hisense EUROPE

Date 04.11.2022
Time 09:05:19

Type	FR714A-DED42	Brand name	ELVITA
Model	CCS47232V	Version	10.06.2021
Art. No.	739327	Service index	01


772240



Position	Ident	Spare part description	Quantity	Validity	Extra ID
0001	548088	OVEN ELECTRIC	1		
0002	559541	CHIMNEY ASSEMBLY FS50	1		
0004	562206	BOTTOM HEATER PROTECTIVE SHIELD FS50	1		
0005	569283	OVEN CASING INSULATION E FS16-50	1		
0006	563163	CENTRAL CROSS PROFILE OVEN FS50	1		
0007	780161	THERMOSTAT SENSOR CLAMP NG3 EEI	1		
0008	569257	BACK PANEL INSULATION E LV FS-50	1		
0010	667800	HINGE HOUSING NGVA II	2		
0014	567390	OVEN GASKET FS16-50 CLOSED	1		
0015	235270	DOOR SPACER	2		
0032	564554	CENTRAL CROSS PROFILE INSERT FS70C	2		

Position	Ident	Spare part description	Quantity	Validity	Extra ID
0033	574965	FRONT WALL OVEN F FS70C BM ENAMELED	1		
0038	712372	CAPILAR THERMOSTAT GASKET	1		
0110	564966	BOTTOM PROTECTION SHIELD FS70 PRESS2	1		
1434	661634	DOOR LOCK ASSY	1		
1607	704119	FIXING SPRING	4		


773222




Position	Ident	Spare part description	Quantity	Validity	Extra ID
0026	564522	CROSS BRACE FS70	1		
0099	722379	DRAWER GUIDE HOLDER FS70C	4		
0101	822364	SIDE PANEL WH	2		
0104	572919	BACK WALL FS70 E	1		
0105	567807	BOTTOM CROSS PROFILE CYL700 WHITE	1		
0111	877541	DRAWER GUIDE - RIGHT	1		
0112	877542	DRAWER GUIDE - LEFT	1		
0114	721943	SIDE STRIP RIGHT FS60 070 MOR	1		
0115	721942	SIDE STRIP LEFT FS60 070 MOR	1		
0116	822388	PLINTH	1		
0274	709742	BASE PLUG 070	4		

Position	Ident	Spare part description	Quantity	Validity	Extra ID
1604	807423	WEIGHT	1		
1614	579461	CONNECTION BOX SHIELD FS16	1		
1615	799155	COOKTOP HOLDER - LEFT	1		
1616	799156	COOKTOP HOLDER - RIGHT	1		
1622	799152	CONTROL PANEL HOLDER - LEFT	1		
1623	799154	CONTROL PANEL HOLDER - RIGHT	1		


774263



Position	Ident	Spare part description	Quantity	Validity	Extra ID
0201	722211	DRAWER V XXL FS70C BK070 ASSY	1		
0202	722139	DRAWER COVER FS70C CYL BK070	1		
0203	877506	DRAWER XXL FS60	1		
0205	564490	OVEN GRID FS50 CR	1		
0206	565061	SHALLOW BAKING TRAY FS50 ENAMELED	2		
0220	788593	FOOT	2		
0233	565080	DEEP BAKING TRAY FS50 ENAMELED	1		
0273	432038	CONSOLE	1		
1701	564498	BAKING PAN WIRE GUIDE FS16 NG3 CR	2		




Position	Ident	Spare part description	Quantity	Validity	Extra ID
0301	861176	OVEN DOOR WH	1		
0302	819088	OVEN DOOR GLASS FS70G 500-ELV203 WH	1		
0304	573012	HINGE XTURNSOFT FS60 3S	2		
0305	567382	HANDLE TUBE R6-201 FS16-60 070	1		
0308	419518	SCREW M5X40-H ISO7045 ČRNÍ	2		
0310	440277	SCREW ST4,8X13 DIN7982 C H BLACK	2		
0311	567365	HANDLE HOLDER R6-201 9005	2		
0316	798218	DOOR AIR GUIDE	1		
0322	567233	DOOR GLASS-INNER FS60 9005	1		
0323	425763	DOOR COVER SPACER	2		
0324	623050	GLASS OVEN DOOR FS60-2 INTERNAL	1		
1046	798215	LOCK PIN	1		
1360	421160	RUBBER CARRIER DOOR GLASS	2		
1374	423096	INTERMEDIATE GLASS HOLDER HF L	1		
1376	423002	INTERMEDIATE GLASS HOLDER HF D	1		




Position	Ident	Spare part description	Quantity	Validity	Extra ID
0406	588225	KNOB GE 6-201B EP-BL-G 070/7005	1		
0408	819463	CONTROL PANEL 070	1		
0409	588260	KNOB GE 6-201B EN 070/7005	4		
0411	802643	KNOB 070/7005	1		
0440	354924	LENS RU AN_EL 150C	1		
0440A	667951	LAMP LENS A RD35/303MATALFLE	1		
0442	354923	SIGNAL LAMP S43-A AN_EL 240V L280 150C	2		
0450	798999	WIRING HARNESS	1		
0613M	546324	ENERGY SWITCH-SINGLE CIRCUIT 50.8	4		
0617	276302	OVEN THERMOSTAT - CAPILLARY TECASA	1		
0679	726612	SELECTOR SWITCH	1		
1771	623219	COOKTOP SUPPORT FS16	2		

777274



Position	Ident	Spare part description	Quantity	Validity	Extra ID
0401	818982	GLASSCERAMIC COOKTOP 070	1		
0421	570154	RESIDUAL HEAT INDICATOR HOLDER FS16	1		
0423	681130	RESIDUAL HEAT INDICATOR-LOW T B 250V	1		
0462	553893	HI-LIGHT RADIANT HEATER 230V 1200W 145 1	2		
0463	554328	HI-LIGHT RADIANT HEATER 230V/1800W/D180	1		
0465	554329	HI-LIGHT RADIANT HEATER 230V/2300W/D210	1		
0606H	555855	WIRING HARNESS SKP-1K-EGO-FS16	2		
0606M	833908	WIRING HARNESS	2		
0606P	392561	CONDUCTOR A606G.120-06-855	1		
0607	548215	HOT PLATE FIXING SPRING D 145BR ZA SEV.G	2		
0607D	422875	HOT PLATE FIXING SPRING	1		
0607V	548216	HOT PLATE FIXING SPRING D180BR ZA SEV.GR	1		

77A325



Position	Ident	Spare part description	Quantity	Validity	Extra ID
0615P	690653	SWITCH HOLDER FS50 VS	1		
0618	469257	CUT-OUT THERMOSTAT 150C TIANPENG	1		
0641	304858	LAMP G9 25W BJB	1		
0644	564204	TUBULAR HEATER ZI FS50 230V 1100/1600W	1		
0645	564239	TUBULAR HEATER C FS50 230V 2100W	1		
0646	564202	TUBULAR HEATER B FS50 230V 1000W	1		
0649	783231	CONNECTING TERMINAL	1		
0660	602942	VEN FAN KELI 230V FS16	1		
0667	563172	FAN COVER NG3(FS16) ENAMELED	1		
0672	713429	FAN BLADE	1		
0710	726505	ENERGY SWITCH DUTY CYCLE 25DC EGO	1		
0727	712371	OVEN FAN MOTOR SHAFT GASKET NG3	1		
0728	712375	TOP HEATER GASKET CERAMIC PAPER	1		
0729	712378	GASKET ROUND HEATER CERAMIC PAPER	1		
0931	711655	WIRING HARNESS FS16 VENT	1		
0934	811696	COOLING FAN 230V	1		
0935	812358	COOLING CHANNEL FS16 RADIAL	1		
0936	812357	PARTITION SHEET MET.PART HV FS16	1		
0937	830344	PROTECTION HV RADIAL FS16	1		