


SPARE PARTS LIST

Hisense EUROPE

Date 04.11.2022
Time 09:32:23

Type	FC611A-ASDX2	Brand name	ELVITA
Model	CGS3640V	Version	15.04.2020
Art. No.	736156	Service index	02


772240



Position	Ident	Spare part description	Quantity	Validity	Extra ID
0001	825764	OVEN	1		
0002	559541	CHIMNEY ASSEMBLY FS50	1		
0004	562206	BOTTOM HEATER PROTECTIVE SHIELD FS50	1		
0005	569283	OVEN CASING INSULATION E FS16-50	1		
0006	563163	CENTRAL CROSS PROFILE OVEN FS50	1		
0007	780161	THERMOSTAT SENSOR CLAMP NG3 EEI	1		
0008	825787	BACK PANEL INSULATION	1		
0010	667800	HINGE HOUSING NGVA II	2		
0014	567390	OVEN GASKET FS16-50 CLOSED	1		
0015	235270	DOOR SPACER	2		
0032	564551	CENTRAL CROSS PROFILE INSERT FS60C	2		

Position	Ident	Spare part description	Quantity	Validity	Extra ID
0033	574932	FRONT WALL OVEN F FS60C BM ENAMELED	1		
0038	712372	CAPILAR THERMOSTAT GASKET	1		
0110	564956	SHEET PROTECTIVE FS60	1		
1434	661634	DOOR LOCK ASSY	1		
1607	704119	FIXING SPRING	4		


773218




Position	Ident	Spare part description	Quantity	Validity	Extra ID
0026	565582	CROSS BRACE FS60	1		
0098	671364	FIXING PLATE FOR POWER UNIT	2		
0099	567568	DRAWER GUIDE HOLDER FS60C RAW	4		
0101	567813	SIDE WALL CYL WHITE	2		
0104	572887	PANEL - PROTECTIVE FS60 E	1		
0105	567804	BOTTOM CROSS PROFILE CYL600 WHITE	1		
0111	567589	DRAWER GUIDE R FS60C RAW	1		
0112	567591	DRAWER GUIDE L FS60C RAW	1		
0114	554643	SIDE BAR RIGHT FS16 WHITE	1		
0115	554630	SIDE BAR LEFT FS16 WHITE	1		
0116	715719	TELESCOPIC PLINTH FS60 100 BE	1		
0274	709742	BASE PLUG 070	4		

Position	Ident	Spare part description	Quantity	Validity	Extra ID
1604	666942	WEIGHT FS50 3,5 KG	1		
1614	579461	CONNECTION BOX SHIELD FS16	1		
1615	799155	COOKTOP HOLDER - LEFT	1		
1616	799156	COOKTOP HOLDER - RIGHT	1		
1622	799152	CONTROL PANEL HOLDER - LEFT	1		
1623	799154	CONTROL PANEL HOLDER - RIGHT	1		


774205



Position	Ident	Spare part description	Quantity	Validity	Extra ID
0201	598379	DRAWER FS60C BK070 ASSY	1		
0202	567852	DRAWER COVER FS60C WELDED BK070	1		
0203	566647	DRAWER VESSEL FS60	1		
0204	850767	DRAWER PIN 3479-09-103	4		
0205	564490	OVEN GRID FS50 CR	1		
0206	565061	SHALLOW BAKING TRAY FS50 ENAMELED	2		
0220	788593	FOOT	2		
0233	565080	DEEP BAKING TRAY FS50 ENAMELED	1		
0273	432038	CONSOLE	1		
1701	564498	BAKING PAN WIRE GUIDE FS16 NG3 CR	2		




Position	Ident	Spare part description	Quantity	Validity	Extra ID
0301	818091	OVEN DOOR 070	1		
0302	818040	DOOR GLASS FS60G 500-ELV203 WH GLU	1		
0304	570152	OVEN DOOR HINGE FS60 2S	2		
0305	567382	HANDLE TUBE R6-201 FS16-60 070	1		
0308	419518	SCREW M5X40-H ISO7045 ČRNI	2		
0310	440277	SCREW ST4,8X13 DIN7982 C H BLACK	2		
0311	567365	HANDLE HOLDER R6-201 9005	2		
0316	798216	DOOR AIR GUIDE	1		
0322	567233	DOOR GLASS-INNER FS60 9005	1		
0323	425763	DOOR COVER SPACER	2		
1046	798215	LOCK PIN	1		
1374	423096	INTERMEDIATE GLASS HOLDER HF L	1		
1376	423002	INTERMEDIATE GLASS HOLDER HF D	1		



Position	Ident	Spare part description	Quantity	Validity	Extra ID
0406	588225	KNOB GE 6-201B EP-BL-G 070/7005	1		
0408	818180	CONTROL PANEL 070	1		
0409	588234	KNOB GE 6-201B E7 070/7005	4		
0411	588203	KNOB 070/7005	1		
0440	354924	LENS RU AN_EL 150C	1		
0440A	667951	LAMP LENS A RD35/303MATALFLE	1		
0442	680112	INDICATOR S43-A AN_EL 400V L280 150C	2		
0450	825742	WIRING HARNESS	1		
0617	276302	OVEN THERMOSTAT - CAPILLARY TECASA	1		
0678	710678	SWITCH DUO BLOCK 7-7-65	2		
0679	466265	SELECTOR SWITCH K15A EUREL	1		
1771	623219	COOKTOP SUPPORT FS16	2		

777236



0618

0641

0728

0644

0646

0649

0650

Position	Ident	Spare part description	Quantity	Validity	Extra ID
0618	639499	PROTECTIVE THERMOSTAT 135STC ELTH	1		
0641	304858	LAMP G9 25W BJB	2		
0644	564205	TUBULAR HEATER ZI FS50 400V 1100/1600W	1		
0646	564203	TUBULAR HEATER SP FS50 400V 1000W	1		
0649	783231	CONNECTING TERMINAL	1		
0650	703441	POWER CORD 16A/400V	1		
0728	712375	TOP HEATER GASKET CERAMIC PAPER	1		