

SPARE PARTS LIST


Hisense EUROPE

Date 04.11.2022
Time 10:07:08

Type FI614A-GPJ42
Model CIS5623X
Art. No. 736161

Brand name ELVITA
Version 18.05.2020
Service index 02


772240




Position	Ident	Spare part description	Quantity	Validity	Extra ID
0001	548088	OVEN ELECTRIC	1		
0002	559541	CHIMNEY ASSEMBLY FS50	1		
0004	562206	BOTTOM HEATER PROTECTIVE SHIELD FS50	1		
0005	569283	OVEN CASING INSULATION E FS16-50	1		
0006	563163	CENTRAL CROSS PROFILE OVEN FS50	1		
0007	780161	THERMOSTAT SENSOR CLAMP NG3 EEI	1		
0008	569257	BACK PANEL INSULATION E LV FS-50	1		
0010	667800	HINGE HOUSING NGVA II	2		
0014	567390	OVEN GASKET FS16-50 CLOSED	1		
0015	235270	DOOR SPACER	2		
0032	564551	CENTRAL CROSS PROFILE INSERT FS60C	2		

Position	Ident	Spare part description	Quantity	Validity	Extra ID
1604	807423	WEIGHT	1		
1614	579461	CONNECTION BOX SHIELD FS16	1		
1615	799155	COOKTOP HOLDER - LEFT	1		
1616	799156	COOKTOP HOLDER - RIGHT	1		
1622	799152	CONTROL PANEL HOLDER - LEFT	1		
1623	799154	CONTROL PANEL HOLDER - RIGHT	1		


774205



Position	Ident	Spare part description	Quantity	Validity	Extra ID
0201	617417	DRAWER FS60C VZ065 ASSY	1		
0202	617409	DRAW COVER FS60C VZ065 GLUED	1		
0203	566647	DRAWER VESSEL FS60	1		
0204	850767	DRAWER PIN 3479-09-103	4		
0205	564490	OVEN GRID FS50 CR	1		
0206	565061	SHALLOW BAKING TRAY FS50 ENAMELED	2		
0220	788593	FOOT	2		
0233	565080	DEEP BAKING TRAY FS50 ENAMELED	1		
0273	432038	CONSOLE	1		
1701	564498	BAKING PAN WIRE GUIDE FS16 NG3 CR	2		




Position	Ident	Spare part description	Quantity	Validity	Extra ID
0301	818996	OVEN DOOR 065	1		
0302	818599	OVEN DOOR GLASS 065	1		
0304	570151	HINGE XTURN SOFT FS60 2S	2		
0305	567380	HANDLE TUBE R6-201 FS16-60 065	1		
0308	419518	SCREW M5X40-H ISO7045 ČRNÍ	2		
0310	440277	SCREW ST4,8X13 DIN7982 C H BLACK	2		
0311	567365	HANDLE HOLDER R6-201 9005	2		
0316	798218	DOOR AIR GUIDE	1		
0322	567233	DOOR GLASS-INNER FS60 9005	1		
0323	425763	DOOR COVER SPACER	2		
1046	798215	LOCK PIN	1		
1374	423096	INTERMEDIATE GLASS HOLDER HF L	1		
1376	423002	INTERMEDIATE GLASS HOLDER HF D	1		




Position	Ident	Spare part description	Quantity	Validity	Extra ID
0406	588226	KNOB GE 6-201B EP-BL-G 022/9005	1		
0408	819381	CONTROL PANEL VZ065	1		
0411	802644	KNOB 022/9005	1		
0440	354924	LENS RU AN_EL 150C	1		
0440A	667951	LAMP LENS A RD35/303MATALFLE	1		
0442	354923	SIGNAL LAMP S43-A AN_EL 240V L280 150C	2		
0450	786231	WIRING HARNESS	1		
0617	276302	OVEN THERMOSTAT - CAPILLARY TECASA	1		
0679	726612	SELECTOR SWITCH	1		
1771	623219	COOKTOP SUPPORT FS16	2		

777263



Position	Ident	Spare part description	Quantity	Validity	Extra ID
0401	819008	GLASSCERAMIC COOKTOP 045	1		
0606	816323	WIRING HARNESS FS16-IND.	1		
0649I	783231	CONNECTING TERMINAL	1		
1248	708669	POWER BOARD 7G 4IG	1		
1249	708652	FILTER BOARD 7G	1		
1256	809323	INDUCTION SYSTEM COPRECI 7G 4IG60-FS60	1		
1257	708653	INDUCTION COIL 7G 145S	1		
1258	795824	INDUCTION COIL 7G 180	2		
1259	708655	INDUCTION COIL 7G 210L	1		
1260	708663	COOLING FAN 7G	1		
1261	810448	USER INTERFACE 7G UI 4IG-G	1		
1262	685455	MODULE GASKET FS16	1		

77A316



Position	Ident	Spare part description	Quantity	Validity	Extra ID
0615P	690653	SWITCH HOLDER FS50 VS	1		
0618	469257	CUT-OUT THERMOSTAT 150C TIANPENG	1		
0641	304858	LAMP G9 25W BJB	1		
0644	564204	TUBULAR HEATER ZI FS50 230V 1100/1600W	1		
0645	564239	TUBULAR HEATER C FS50 230V 2100W	1		
0646	564202	TUBULAR HEATER B FS50 230V 1000W	1		
0649	783231	CONNECTING TERMINAL	2		
0660	602942	VEN FAN KELI 230V FS16	1		
0667	563172	FAN COVER NG3(FS16) ENAMELED	1		
0672	713429	FAN BLADE	1		
0710	726505	ENERGY SWITCH DUTY CYCLE 25DC EGO	1		
0727	712371	OVEN FAN MOTOR SHAFT GASKET NG3	1		
0728	712375	TOP HEATER GASKET CERAMIC PAPER	1		
0729	712378	GASKET ROUND HEATER CERAMIC PAPER	1		
0931	711655	WIRING HARNESS FS16 VENT	1		
0934	713230	COOLING FAN PYR 230V	1		
0935	812358	COOLING CHANNEL FS16 RADIAL	1		
0936	812357	PARTITION SHEET MET.PART HV FS16	1		